

#### 1. Using your X2 Transponder

After activating and installing your X2 Transponder, it is time to start using it!

#### Rechargeable:

Before racing, make sure your X2 Transponder is charged through the X2 RaceKey. Also, the X2 RaceKey doesn't need to be connected during the race.

#### Direct Power:

Place the X2 RaceKey in the X2 RaceKey Mount during racing.

# 2. Battery status, or subscription

If you are unsure about your transponder's battery status, or about your subscription?

The LED lights on the X2 RaceKey help you out! Check section **3.2 Indicator light (LED) signals** in the manual for more information. The user manual is available on the 'attachments' tab of the product description page.

#### 3. Not racing every weekend?

When you haven't used your X2 Transponder for a while, be sure to connect it to your X2 RaceKey before you start using it again.

### 4. Battery management

To prepare your X2 Transponder the battery will need to be charged at least for 4 hours.

## Important note:

Please make sure to charge the transponder at least with intervals of 6 months to secure a healthy battery. Don't keep the transponder on a charger longer than necessary.

### 5. X2 Transponders feature supercharging

The X2 Transponder will fully charge in only 4 hours. A fully charged X2 Transponder will enable you to use it for 5 days - which will easily get you through a weekend filled with training sessions and races.

If you forget to charge the transponder before the race an hour of charging will make it last for a day!